



No.	Plan	Article	Qty
1	FRONT BUMPER	2998633	1
2	DUAL LOCK TAPE	2998521	2
3	SCREW M5X45 DIN912	3991349	2
4	NUT M5	1001679	2
5	P00108118	2915604	1
6	SCREW M5x12	2993078	2

- Before stick 3M Dual Lock prepare surface on plastic part:
1. Roughen the surface by abrasive pad
 2. Clean surface with Isopropyl Alcohol (IPA), propan-2-OL.
 3. Press 3M Dual Lock after stick

NOTICE: THE INFORMATION CONTAINED ON THIS DRAWING IS PROPRIETARY TO VERMEIREN GROUP AND SHALL NOT BE DISCLOSED IN WHOLE OR IN PART, OR USED FOR ANY DESIGN OR MANUFACTURE, EXCEPT WHEN SUCH USER POSSESSES DIRECT WRITTEN AUTHORIZATION FROM VERMEIREN GROUP.

SV SYNC FRONT BUMPER SUB-ASSEMBLY

Scale:	1:3	Drafted	Verified	Confirmed
Date	29/08/2025	15/01/2026	15/01/2026	
Initials	BK	MK	MK	

Plan No.
E00108117/A.2

